+ AUTODOC CLUB

How to change front strut mount on **Mercedes W169** – replacement guide







VIDEO TUTORIAL



(i) Important!

This replacement procedure can be used for:

MERCEDES-BENZ A-Class (W169) A 200 CDI (169.308, 169.008), MERCEDES-BENZ A-Class (W169) A 170 (169.032, 169.332), MERCEDES-BENZ A-Class (W169) A 200 (169.033, 169.333), MERCEDES-BENZ A-Class (W169) A 160 CDI (169.006, 169.306), MERCEDES-BENZ A-Class (W169) A 180 CDI (169.007, 169.307), MERCEDES-BENZ A-Class (W169) A 200 CDI (169.008, 169.308), MERCEDES-BENZ B-Class (W245) B 180 CDI (245.207), MERCEDES-BENZ B-Class (W245) B 200 CDI (245.208), MERCEDES-BENZ B-Class (W245) B 170 (245.232), MERCEDES-BENZ B-Class (W245) B 200 (245.233), MERCEDES-BENZ B-Class (W245) B 200 TURBO (245.234), MERCEDES-BENZ B-Class (W245) B 150 (245.231), MERCEDES-BENZ A-Class (W169) A 200 TURBO (169.034, 169.334), MERCEDES-BENZ B-Class (W245) B 170 NGT (245.233), MERCEDES-BENZ A-Class (W169) A 160 (169.031, 169.331), (+ 3)

The steps may slightly vary depending on the car design.


CLUB.AUTODOC.CO.UK 1–16







REPLACEMENT: STRUT MOUNT – MERCEDES W169. TOOLS YOU NEED:



- Wire brush
- WD-40 spray
- Brake cleaner
- Copper grease
- Combination spanner #16
- Combination spanner #21
- Drive socket # E12
- Drive socket # 21
- HEX bit no.H6.

- Wheel impact socket #17
- Ratchet wrench
- Torque wrench
- Flat Screwdriver
- Crow bar
- Water pump pliers
- Hydraulic strut spring compressor
- Wheel chock

BUY TOOLS

CLUB.AUTODOC.CO.UK 2-16







Replacement: strut mount – Mercedes W169. Professionals recommend:

- All mounts of the front shock struts should be replaced simultaneously.
- The replacement procedure is identical for the mounts of the left and right shock struts of the front suspension.
- Be sure to replace all self-locking nuts and bolts during installation.
- All work should be done with the engine stopped.

REPLACEMENT: STRUT MOUNT – MERCEDES W169. RECOMMENDED SEQUENCE OF STEPS:

1

Secure the wheels with chocks.



Loosen the wheel mounting bolts. Use wheel impact socket #17.



Raise the front of the car and secure on supports.

CLUB.AUTODOC.CO.UK 3-16







Unscrew the wheel bolts.



AUTODOC recommends:

- Important! Hold the wheel while unscrewing the fastening bolts. Mercedes W169
- Remove the wheel.



- 6 Clean the stabiliser link fasteners. Use a wire brush. Use WD-40 spray.
- Unscrew the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use HEX No.H6. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 4-16







Disconnect the ABS sensor cable fastener. Use water pump pliers. Use a crowbar.



Disconnect the cable fastener of the brake pads wear sensor from the shock absorber strut. Use a crowbar.



Dismantle the retainer. Use a crowbar.



- Clean the fasteners connecting the shock strut to the steering knuckle. Use a wire brush. Use WD-40 spray.
- Unscrew the lower fastener connecting the shock strut to the steering knuckle. Use a combination spanner #21. Use a drive socket #21. Use a ratchet wrench.



CLUB.AUTODOC.CO.UK 5-16







Remove the fastening bolts.



- Disconnect the steering knuckle from the shock absorber strut.
- Lower the car. Open the hood.



- Use a fender protection cover to prevent damaging paintwork and plastic parts of the car.
- Unscrew the top fastening of the shock strut mount. Use a drive socket #E12. Use a ratchet wrench.



Remove the coolant reservoir.



CLUB.AUTODOC.CO.UK 6-16








Remove the suspension strut. Use a crowbar.



Set the shock absorber strut on the spring compressor tool.



Replacement: strut mount – Mercedes W169. AUTODOC recommends:

- Note that when using a spring compressor, spring coils need to be securely gripped, compressing the spring on the opposite sides.
- Ensure the correct position of the spring in the retainer.
- Make sure that the spring coils tightly entered the lock handles.
- Compress the spring.
- Remove the protective cap from the shock absorber strut mount. Use a flat screwdriver.



CLUB.AUTODOC.CO.UK 7–16







Treat the shock strut rod. Use a wire brush. Use WD-40 spray.



Remove the strut piston rod nut. Use a drive socket #21. Use HEX No.H6. Use a ratchet wrench.



Remove the top strut mount. Use a crowbar.



Replacement: strut mount – Mercedes W169. Tip:

• Examine the shock absorber dust cap and the bump stop. Replace them if necessary.

26 Install a new strut mount.



CLUB.AUTODOC.CO.UK 8-16







Tighten the shock strut piston rod nut. Use a drive socket #21. Use HEX No.H6. Use a torque wrench. Tighten it to 65 Nm torque.



Replacement: strut mount – Mercedes W169. AUTODOC experts recommend:

- Check to make sure the spring is positioned correctly. Avoid its misalignment.
- Treat the shock strut rod. Use copper grease.



Install the protective cap onto the shock absorber strut mount.



Decompress the spring.

CLUB.AUTODOC.CO.UK 9-16







Remove the assembled shock strut.



- Install the shock strut into the wheel arch.
- Tighten the shock strut top mount. Use a drive socket #E12. Use a torque wrench. Tighten it to 20 Nm torque.+45°



AUTODOC recommends:

- Important! Be sure to use new fasteners.
- 34 Install the coolant reservoir.



CLUB.AUTODOC.CO.UK 10-16







Remove the fender protection cover. Close the hood.



- Raise the front of the car and secure on supports.
- Fix the shock absorber strut on the steering knuckle. Install the fastening bolts.



Tighten the lower fasteners connecting the shock strut to the steering knuckle. Use a combination spanner #21. Use a drive socket #21. Use a torque wrench. Tighten it to 120 Nm torque.+90°



AUTODOC recommends:

• Important! Be sure to use new fasteners.

CLUB.AUTODOC.CO.UK 11-16







Install the bracket onto the shock absorber strut.



- Connect the brake pad wear sensor plug.
- Connect the ABS sensor wiring.

44

Tighten the fastener connecting the stabilizer link to the stabilizer bar. Use a combination spanner #16. Use HEX No.H6. Use a torque wrench. Tighten it to 60 Nm torque.



Treat the shock strut fasteners. Use copper grease.



Treat the surface where the brake disc contacts the wheel rim. Use copper grease.



CLUB.AUTODOC.CO.UK 12-16







Clean the brake disk surface. Use a brake cleaner.



AUTODOC recommends:

• Replacement: strut mount – Mercedes W169. After applying the spray, wait a few minutes.

46

Install the wheel.



Replacement: strut mount – Mercedes W169. Tip from AUTODOC:

• To avoid injury, hold up the wheel when screwing in the fastening bolts.

47

Screw in the wheel bolts. Use wheel impact socket #17.



CLUB.AUTODOC.CO.UK 13-16







Lower the car and working in a cross order, tighten the wheel bolts. Use wheel impact socket #17. Use a torque 48 wrench. Tighten it to 120 Nm torque.



49

Remove the jacks and chocks.








VIEW MORE TUTORIALS

CLUB.AUTODOC.CO.UK 14-16





AUTODOC — TOP QUALITY AND AFFORDABLE CAR PARTS ONLINE



A GREAT SELECTION OF SPARE PARTS FOR YOUR CAR

BUY SPARE PARTS FOR MERCEDES

STRUT MOUNT: A WIDE SELECTION

CLUB.AUTODOC.CO.UK 15-16





CHOOSE CAR PARTS FOR MERCEDES W169

STRUT MOUNT FOR MERCEDES: BUY NOW

STRUT MOUNT FOR MERCEDES W169: THE BEST DEALS & OFFERS

① DISCLAIMER:

The document contains only general recommendations that may be useful for you when you perform repair or replacement work. AUTODOC shall not be liable for any loss, injury, damage of property occurring in the repair or replacement process due to incorrect use or misinterpretation of the provided information.

AUTODOC shall not be liable for any possible mistakes and uncertainties in this guide. The information provided is for information purposes only and cannot replace advice from specialists.

AUTODOC shall not be liable for incorrect or hazardous usage of equipment, tools and car parts. AUTODOC strongly recommends to be careful and observe the safety rules when performing repair or replacement works. Remember: usage of low quality auto parts does not guarantee you the appropriate level of road safety.

© Copyright 2023 – All the contents of this website, in particular texts, photographs and graphics, are protected by copyright. All rights, including reproduction, publication, editing and translation rights, are reserved by AUTODOC GmbH.

CLUB.AUTODOC.CO.UK 16-16